



## LOS2400H: Sensor and Switch Pack

### Application & Mounting Notes


The narrow end of the LOS2400H must be mounted in the direction shown in the diagram below.

The sensor is more sensitive to movement ACROSS its pattern than if a person walks directly toward the sensor. Crossing zones is best and the installer should keep this in mind when using any passive infrared technology

The closer the movement is to the sensor, the SMALLER the movement is needed to trigger the sensor. The opposite is also true...if you are far away from the sensor it will take a LARGER movement to trigger the sensors.

### Coverage Pattern:

16'x 80' (sensor should ideally be mounted at 9'-11' for maximum coverage)



RAB Electric Manufacturing, Inc.  
170 Ludlow Avenue  
Northvale, New Jersey 07647

888 722-1000  
888 722-1232 (fax)  
sales@rabweb.com (e-mail)  
www.rabweb.com